


Collect Decoration panel and Sales panel with digital print

Decoration panel <u>without</u> metal insert, Sales panel <u>with</u> metal insert for fixing of magnetic sheves and magnetic brochure holders



Assembly instruction Decoration panel:

- 1. Attach aluminium framework to the wall, top edge of panel 200 cm from floor. Observe vertical and horizontal alignment.
 - First transfer 4 drillings (see arrows on page 1) from framework onto the wall, than drill holes for dowels and attach framework with suitable mounting material.
- 2. Push textile print with circulating piping into the groove of the aluminum frame, start in a corner. Now the digital print is wrinkle-free strained.

Assembly instruction Sales panel:

- 1. Attach aluminium framework to the wall, top edge of panel 200 cm from floor. Observe vertical and horizontal alignment.
 - First transfer 4 drillings (see arrows on page 1) from metal insert onto the wall, than drill holes for dowels and attach framework with suitable mounting material.
- 2. Push textile print with circulating piping into the groove of the aluminum frame, start in a corner. Now the digital print is wrinkle-free strained.

Fixing of magnetic shalves and magnetic brochure holder:

- 1. Determine attachment position
- 2. First place magnetic shelf or magnetic brochure holder in position above, thereby observe vertical and horizontal alignment. Then swing down to the panel surface (see illustr. 2). Magnetic shelf or magnetic brochure holder is liable now firmly at the panel.
- 3. Solving in reverse order.
- 4. Load capacity: magnetic shelves max. 7 kg, magnetic brochure holder max. 3 kg

